


# EXO® Louvre Systems Warranty and Maintenance Guide.



## Warranty

All EXO products Fabricated and Installed by Manson Engineering, is from the date of invoice, fully warranted for the first two years. This warranty covers workmanship, louvres, balustrades, componentry, actuators, switches and electronics.

All aluminium louvres and balustrade extrusions used in EXO louvre systems are Fabricated in New Zealand to AS1866 & AS3902 standards. Marine grade T316 stainless steel is used for fixings being standard. Plastic injected molded componentry is all UV stabilised.

Dulux Duralloy or equivalent is the standard finish supplied unless stated otherwise and provides excellent resistance to weather and salt spray. This carries warranties of a maintainable service life of 25 years, film integrity of 10 years and colour integrity of 7 years.

EXO products are designed to conform to New Zealand and Australian standards wind loadings. Any additional items purchased through Manson Engineering and not fabricated by Manson Engineering will be subject to the manufacturer's warranty.

## Maintenance Guide

The EXO louvre roof system is built using aluminium, with a 10-year guarantee on powder coating finishes, designed to last the test of time and New Zealand's harsh weather conditions. Basic maintenance requirements will increase the lifetime and quality of your purchase as well as ensure you are covered under our warranty.

All aluminium frames and blades should regularly be cleaned of any dirt or dust that is sitting on the surface.

Powder coated aluminium should be cleaned every 3 months to ensure the finish remains at the high standard it was at installation.

It is essential that you do a 3 monthly maintenance clean on all parts of your roof as detailed below:

1. Remove any dirt and debris with a damp cloth or sponge.
2. If required to remove stubborn dirt use a mild household detergent but ensure you do not use an abrasive brush at anytime.
3. Rinse off all detergent with water to ensure no detergent remains on the surface.

We also recommend monthly water washes to ensure unnecessary dirt is not sitting on the product. It is always best practise to remove any dirt or debris as they occur. Do not use anything harsher than a mild household detergent to remove any dirt or debris.